

H51/H52 戰術上軌道組-使用說明

H51/H52 TACTICAL RAIL-LONG



1. 退出槍身插銷
2. 將雙邊戰術護木固定螺絲調整至(開啟)
3. 取下上戰術護木
4. 按下槍身分離快拆, 分離上下槍身
5. 退出視孔固定螺絲, 分離視孔組與視孔固定座
6. 將戰術軌道與導槽結合, 並安裝至上槍身, 鎖上戰術軌道固定螺絲
(需鎖附至視孔固定座)
7. 結合上下槍身, 結合槍身插銷接上電源線組
8. 將上戰術護木裝上, 並調整護木固定螺絲至(關閉),
戰術軌道安裝完成

1. Take off the pin from receiver
2. Turn the screw on the handguard to be "open" position
3. Remove the upper handguard
4. Push the quick releasing button to disassemble the upper and lower receiver
5. Turn on the screw on the sight set, remove sight set and mount
6. Combine the tactical rail and guide trough, then assemble to the upper receiver.
Turn in the screw into the tactical rail. (have to lock rail the sight mount)
7. Combine the upper and lower receiver, put in the pin, connect the wire
8. Assemble the upper handguard and turn the screw to be "close" position